


SPEEDROOTER 92R PARTS LIST

| ITEM NO. | CATALOG NO. | DESCRIPTION | ITEM NO. | CATALOG NO. | DESCRIPTION |
|----------|-------------|--|----------|-------------|---|
| 170640 | S92-100-R | Frame Complete w/Axle | 136000 | GFI-20 | 20 ft. Power Cord w/GFCI |
| 170650 | S92-101-R | Frame Only w/Axle | 170910 | S92-605-R | Air Foot Switch & Reverse Switch Assembly |
| 170660 | S92-101-D-R | Rubber Leg Tips | 154326 | S92-605-A | Box Only w/Cover & Screws |
| 156045 | S92-103 | Stair Climber w/Belt (1) | 136170 | S92-605-B | Foot Pedal & Hose |
| 156050 | S92-103-A | Nuts, Bolt, & Washers (2) | 154328 | S92-605-C | Hose Clamp |
| 156055 | S92-103-B | Spacers (2) | 136080 | S92-605-E | Power Switch Diaphragm |
| 170670 | S92-105-R | Handle Hinge | 136210 | S92-605-G-R | Momentary Contact Reverse Switch (Red) |
| 170680 | S92-105-A-R | Handle Hinge Bolts & Nuts (2) | 170920 | S92-605-K | Switch Guard |
| 170690 | S92-106-R | Handle Locking Knobs | 156395 | S92-605-N | Strain Relief Nut |
| 170700 | S92-107-R | Handle Assembly | 156335 | S92-606 | Belt Guard Washer |
| 170710 | S92-107-A-R | Handle - Left | 170930 | S92-609-R | Belt Guard (1/3 hp) w/Slot |
| 170720 | S92-107-B-R | Handle - Right | 170900 | S92-601-R | V-Belt (62") |
| 156075 | S92-107-C | 6" Handle Wheel | 170943 | S92-7000-R | Power Cable Feed Assembly |
| 156080 | S92-107-D | Axle for Handle Wheel | 156350 | S92-7101 | Feed Body |
| 156085 | S92-107-E | Bushings (2) | 156355 | S92-7101-1 | Feed Body for One Piece Feed Control Disk |
| 156090 | S92-107-F | Felt Washers (2) | 156360 | S92-7101-A | Lifting Spring |
| 156105 | S92-107-H | Set Screws (2) | 156363 | S92-7101-B | Guide Pins (2) |
| 170730 | S92-107-J | Rubber Cord Wrap Tip | 155012 | S92-7102 | Mounting Stud |
| 156135 | S92-110 | 10" Wheel w/Retaining Cap (1) | 156370 | S92-7103 | Mounting Knob |
| 156140 | S92-111 | Wheel Retaining Cap (2) | 155020 | S92-7104 | Spout & Retaining Cover |
| 156145 | S92-112 | Axle Spacer (2) | 156355 | S92-7104-1 | Spout for One Piece Feed Control Disk |
| 170740 | S92-113 | Wheel Spacer Washers | 156380 | S92-7105 | Steel Washer |
| 156150 | S92-115 | Axle | 155025 | S92-7200-R | Top Roller Assembly |
| 170750 | S92-116 | Motor Support Spring | 155031 | S92-7210 | Top Carrier Only |
| 170760 | S92-118 | Motor Support Platform | 155035 | S92-7220-R | Swing Pin |
| 170770 | S92-118-B | Guide Screws (2) | 155041 | S92-7225 | Feed Roller Shaft |
| 156168 | S92-118-C | Nuts, Bolt, & Washers (4) | 136120 | S92-7250 | Feed Roller w/Bearing |
| 156170 | S92-120 | Front Bearing Assembly | 155060 | S92-7301 | Feed Pressure Knob |
| 156174 | S92-120-A | Front Bearing Knob | 155062 | S92-7301-A | Limiting Nut |
| 156183 | S92-120-D | Bolts, Nuts, & Washers (2) | 155066 | S92-7315 | Pressure Spring |
| 170780 | S92-180 | Drum Shaft | 155070 | S92-7330 | Ball Bearing |
| 170790 | S92-180-A | Wear Washer | 155076 | S92-7331 | Ball Bearing Holder |
| 170800 | S92-181-1 | Drum Shaft Retaining Bolt w/Grease Fitting | 155080 | S92-7340 | Top Cover |
| 170810 | S92-182 | Retaining Washer | 155085 | S92-7341 | Cover Screws (3) |
| 170820 | S92-183 | Felt Washer | 155092 | S92-7400-R | Bottom Roller Assembly |
| 170823 | S92-184 | High Collar Lock Washer | 155096 | S92-7410 | Bottom Carrier Only |
| 170825 | S92-190 | Guide Tube Holder | 155035 | S92-7420-R | Swing Pin |
| 170630 | S92-200 | Spring Distributor Tube Assembly | 155106 | S92-7425 | Bottom Roller Shaft |
| 170620 | S92-450-R | Open Drum Complete | 136120 | S92-7450 | Bottom Roller w/Bearing |
| 170830 | S92-452-R | Open Drum Shell | 155130 | S92-7530 | Thrust Bearing |
| 170840 | S92-454 | Drum Hub Bearings (2) | 155135 | S92-7540 | Cable Adjustment Plate |
| 170880 | S92-456 | Bushing | 155140 | S92-7541 | Plate Screws (3) |
| 170850 | S92-460-R | Drum Connecting Cable (for 5/8" & 3/4" Cables) w/ Nut, Screw, & Lock Washer | 155145 | S92-7601 | Feed Control Disc w/Lever & Knob |
| 170860 | S92-460-A-R | Connecting Cable Nut, Screw, & Lock Washer | 155182 | S92-7601-A | Lever & Knob |
| 170870 | S92-490 | Inner Drum Cage for Large Drum | 155150 | S92-7601-1 | Feed Control Disk (One Piece) |
| 170873 | S92-490-B | Inner Drum Cage Bushing | 155190 | S92-7635 | Wave Washer |
| 170874 | S92-490-C | Screws & Washers (3) | 155195 | S92-7635-1 | Wave Washer for One Piece Feed Control Disk |
| 170890 | S92-600-R | 1/3 hp Motor Complete w/Air Foot Switch, Reverse Switch, & GFCI | 136110 | PO-703 | Set of Feed Rollers (3) |
| 136180 | S92-602-1 | Slip Clutch | 170950 | S92-TB-R | Tool Box w/Bolts & Nuts |
| 165720 | S92-602-A | Fixed Pulley Half | 156006 | S92-GT | Guide Tube for Speedrooter 92 |
| 165730 | S92-602-B | Spacer | 146160 | GTE | Guide Tube Extension |
| 165740 | S92-602-C | Moveable Pulley Half | 132210 | S92-DECAL | Set of Safety Decals |
| 165750 | S92-602-D | Spring | 132375 | S92-DVD | Instructional DVD |
| 165760 | S92-602-E | Thrust Washer | 170990 | AFH | Condensed Operating Instructions (Instructions w/Chain & Fittings, Connector, & Screw) |
| 165770 | S92-602-F | Thrust Bearing | 157000 | 92ROI | Complete Operating Instructions |
| 165780 | S92-602-G | Retaining Ring | 130080 | SRCS-R | Senior Rental Cutter Set |
| 156325 | S92-603-R | Knob for Belt Guard | 122080 | 100EM5 | Flexicore Cable, 3/4" x 100 ft. w/ Male & Female Conn. |
| | | | 122040 | 100EM4 | Flexicore Cable, 5/8" x 100 ft. w/ Male & Female Conn. |


SPEEDROOTER 92R SCHEMATIC DIAGRAM



IMPORTANT: When ordering, give Serial Number of Machine.

SPEEDROOTER 92R SCHEMATIC DIAGRAM



S92-450-R LARGE DRUM



S92-7000-R

POWER CABLE FEED

**2 PIECE FEED
CONTROL DISK PARTS**



IMPORTANT: When ordering, give Serial Number of Machine.